

Part No. 10-2001

Installation Instructions

- 1. Disconnect aircraft battery.
- 2. Install alternator per included drawing.
- 3. Refer to appropriate engine and airframe service manuals for belt tension and bolt torques.
- 4. Install battery wire with MS25171-2S terminal nipple on 6mm output terminal and torque to 50 in. lb.
- 5. Install ground wire to any of the three 5mm studs on rear of alternator and torque to 35 in. lb.
- 6. Install field wire with MS25171-1S terminal nipple to F1 terminal on rear of alternator and torque to 20 in. lb.
- 7. NOTE: F2 terminal to remain grounded with ground strap <u>UNLESS</u> aircraft voltage regulator is a type "A" regulator using a 2-wire field circuit, in this case remove and discard ground strap from F2 terminal and connect wiring from voltage regulator to F1 and F2 terminals, torque to 20 in. lb.
- 8. If aircraft is equipped with an "alternator out light" circuit, connect that wire to the AUX terminal and torque to 20 in. lbs. Other wise leave AUX terminal open.
- 9. Reconnect aircraft battery.
- 10. Start aircraft and check alternator output for proper operation.

Maintenance Instructions

Annual / 100 hour inspections:

1. Remove drive belt and turn alternator rotor to check condition of bearings for abnormal noise or roughness.

5 year or 1,000 hour intervals:

- 1. Repeat: Annual / 100 hour inspection.
- 2. Remove field brush assembly and inspect brushes for excess wear. Replace brush assembly if brushes extend less than .250" from edge of brush holder case.